




RHINO-RACK

Flexiglass (Flexisport) Canopy Track System (RTCFG01)

Important: Please read these instructions carefully prior to installation. Please refer to your fitting instruction to ensure that the Canopy Rack System is installed in the correct location. Check the contents of kit before commencing fitment and report any discrepancies. Place these instructions in the vehicle's glove box after installation is complete.

Layout



Maximum load carrying capacity: 100kg / 220lbs

Important Information

IMPORTANT INFORMATION

Maximum carrying capacity: 100kg (220lbs) including the weight of the rack system **5kg (11lbs)**.

Please refer to your vehicle manufacturers handbook for maximum carrying capacity. Always use the lower of the two figures. Load must be evenly distributed over the entire basket.

Warning: Do not attempt to fit the canopy rack system to your vehicle unless you fully understand these fitting instructions. Please direct any questions regarding fitting to the dealer from where the roof racks were purchased.

Use only non-stretch fastening ropes or straps.

Recommendations: It is essential that all bolt connections be checked after driving a short distance when you first install your roof racks. Bolt connections should be checked again at regular intervals (once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the roof racks each time they are re-fitted. Always make sure to fasten your load securely. Please also ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible and must be entirely contained within the extents of the roof racks.

Canopy Rack System must be removed when putting vehicle through an automatic car wash.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Off-road use:

The Canopy Rack System may be used in off road applications, however a safety factor of 1.5 is enforced. That is, maximum permissible off road load is **66kg (145lbs)**. Although the crossbars are tested and approved to AS1235-2000, off-road conditions can be much more rigorous. Increasing the number of crossbars does not increase the vehicles maximum permissible roof loading.

Note for Dealers and Fitters:

It is your responsibility to ensure these fitting instructions are given to the end user or client.

Rhino-Rack
3 Pike Street, Rydalmere,
NSW 2116, Australia.
(Ph) (02) 9638 4744
(Fax) (02) 9638 4822








Document No: R297
Prepared By: Scott Murray
Authorised By: Chris Murty

Issue No: 01
Issue Date: 17/06/2013



These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.



Flexiglass (Flexisport) Canopy Track System (RTCFG01)




2 x Crossbars = 5kg



? kg

When these roof racks are to be used on a vehicle that is driven off sealed roads, the maximum roof rack load rating should be **divided by 1.5**. Do not forget to subtract 5kg from your maximum carrying capacity due to the weight of the crossbars and legs.






100kg load rating = **66kg load rating**
(Urban road) = (Off road - 100kg / 1.5)



WARNING! Important Load Carrying Instructions

With utility vehicles, the cabin and the canopy move independently. Roof racks and vehicle can be damaged if the item transported is rigidly fixed at points on both the cabin and canopy. Instead, rigidly fix to either the cabin roof racks or the canopy roof racks.







Flexiglass (Flexisport) Canopy Track System (RTCFG01)

Parts List


Item	Component Name	Part No.	QTY
1	Track - Right	A256	1
2	Track - Left	A256	1
3	M6x35mm T-bolt	B129	4
4	6x3mm O-ring	C347	4
5	M6 Nyloc Knob	M175	4
6	M8x30mm T-bolt	B130	8
7	7x4mm O-ring	C299	8
8	M8 Internal shakeproof washer	W033	8
9	M8x20mm Flat washer	W036	8
10	M8 Tri-star hex dial	N054	8
11	Track End Cap	M525	2
12	Track End Cap	M526	2
13	Fitting Instructions	R297	1

Tools Required




Installation

1 Remove factory installed roof rails.




2 Clean the surface of the canopy






Flexiglass (Flexisport) Canopy Track System (RTCFG01)


3 Mask the canopy as shown.




4 Mark the two (2) centre locations of the canopy as shown, and drill at 6.0mm




5 Remove the mask from the canopy and apply a small amount of butyl mastic to the holes.




6 Remove back tape from foam on underside of tracks.




7 Slide the following T-bolts into the C channel of each track. 1x M8, 2x M6, 1x M8. Install the following O-rings on each T-bolt. 7mm on M8 and 6mm on M6.



8 Install 1x M8 T-bolt through each end cap, and 1x 7mm O-ring, as shown. Slide the endcap assembly into the C channel



9 Fit the track to the canopy, ensure that the cutout on the track is at the rear of the canopy and each bolt is aligned with the corresponding hole.



10 Secure the track to the roof as follows:
M6: 1x M6 Nyloc knob [item 5]
M8: 1x M8 internal shakeproof washer [item 8]
1x M8x19mm flat washer [item 9]
1x M8 tri-star hex dial [item 10]

